

HLG125

2 Inch Offset Adaptor Assembly With Interference Fit Flush Socket




TABLE 3

SOCKET GEAR

HEX SIZE (Matches Collar Driving Hex)	PART NO.
1/4	HLB167-250
5/16	HLB167-312
11/32	HLB167-343
7/16	HLB167-437

TABLE 4

SOCKET GEAR

HEX SIZE (Matches Collar Driving Hex)	PART NO.
1/4	HLB167H-250
5/16	HLB167H-312
11/32	HLB167H-343
7/16	HLB167H-437

ITEM	PART NO.	DESCRIPTION	QTY	PART NO.	QTY
1	HLA1084-()	Tool assy., complete	1	HLA1084H-()	1
2	HLB1174-005	. Air motor assy.	1	HLB1174-005	1
3	HLG125-()	. Offset adaptor assy.	1	HLG125H-()	1
4	AN364-632C	.. Nut, hex	1	AN364-632C	1
5	HLB153-8	.. Spring, leaf	1	--	0
6	HLB157-()	.. Pin, finder	1	--	0
7	HLB105	.. Shaft, intermediate, no. 2	1	HLB105	1
8	B34	.. Bearing (Torrington)	2	B34	2
9	HLB106-11	.. Gear, intermediate, no. 2	1	HLB106-11	1
10	HLB167-() Table 3	.. Gear, socket	1	HLB167H-() Table 4	1
11	HLB159	.. Shaft, intermediate, no. 1	1	HLB159	1
12	HLB106-11	.. Gear, intermediate, no. 1	1	HLB106-11	1
13	HLB169-9	.. Housing assy., complete	1	HLB169-9	1
14	(-13 for .437 socket)			(-13 for .437 socket)	
14	1/4-28 x 5/8 lg.	... Capscrew, socket head	1	1/4-28 x 5/8 lg.	1
15	6-32 x 3/8 lg.	... Screw, countersunk-82°	4	6-32 x 3/8 lg.	4
16	HLB173	... Cover, plate	1	HLB173	1
16	(HLB174 for .437 socket)			(HLB174 for .437 socket)	
17	HLB168-9	... Housing sub-assy.	1	HLB168-9	1
17	(-13 for .437 socket)			(-13 for .437 socket)	
18	B810-5	... Bushing (Boston Gear)	1	B810-5	1
19	HLB103-5	.. Gear, drive	1	HLB103-5	1

HLG125

2 INCH OFFSET ADAPTOR ASSEMBLY with Interference Fit Flush Socket